


## Better Music Builder<sup>®</sup>.com

















\*Note: The back panel may be placed different on actual machines; Please turn off the power and unplug the equipment before changingthe wiring configuration; Miss-connecting may damage equipments.